




801 Church Lane • Easton, PA 18040, USA Toll free (877) 612-5086 • +1 (610) 252-7301 www.follettice.com




Chewblet® Ice Machine Model Number Configurations

Icemake MC Maestro™ Chewblet (400 Seri HC Horizon Chewblet (1000, 14 1650 Seri HM Horizon Micro Che	rm it® ies) it 400, ries)	 Self-contained only. D 115/60/1 (icemaking head) Self-contained and remote. If remote unit, high side is 208-230/60/1. E 230/50/1 (icemaking head) Self-contained only. F 115/60/1 (icemaking head) Remote only. High side is 208-230/60/3. 	Series 400 up to 454 lbs (206kg) 1000 up to 1036 lbs (471kg) 1400 up to 1450 lbs (658kg) 1650 up to 1580 lbs (717kg)	Condenser A Air-cooled, self-contained W Water-cooled, self-contained R Air-cooled, remote condensing unit N Air-cooled, no condensing unit for connection to parallel rack system	Application V Vision™ H Harmony™ B Ice storage bin J Drop-in M Ice Manager diverter valve system	Configuration S RIDE™ (RIDE remote ice delivery equipment) T Top-mount

Read and complete the following 8 installation steps






self-contained

BIN • TOP-MOUNT

Prepare the installation site.

Provide drainage, water supply and electrical power to within 6 feet (2m) of ice machine in accordance with local and national codes. Outdoor installation is not recommended and will void warranty.



Drain 4


• The drain line from the ice machine must have at least 1/4" per foot pitch (6,4mm/0,3m)


BIN • TOP-MOUNT

self-contained

Site preparation

3






Louvered docking assembly


Install the louvered docking assembly.

Δ




- Docking station must be secured in accordance with these instructions to ensure ice machine stability.
- Ventilation openings in the louvered docking station should be clear of obstruction





- Connect ice transport tube to coupling on louvered docking station 2
- Connect ice transport tube to shuttle actuator 3




Internal connections

Connect louvered docking assembly to ice machine.


- Plug must be accessible after final installation.
- H_E1400A/W 230/50/1 requires a 20A circuit (4.00 mm² wire)


Air-cooled ice machines – follow steps 7.1 through 7.4.





10

Water-cooled ice machines – follow steps 7.5 through 7.10.















NOTICE

Ice machine MUST be sanitized prior to operation!

Consult Operation and Service Manual provided with ice machine for sanitizing instructions.



BIN • TOP-MOUNT self-contained



801 Church Lane • Easton, PA 18040, USA Toll free (877) 612-5086 • +1 (610) 252-7301 www.follettice.com



00159905R07 3/13