


Undercounter and Freestanding Integrated Icemaker with Drain Pump

Installation, Operation and Service Manual



Following installation, please forward this manual to the appropriate operations person.

Contents


Welcome	
Before You Begin	. 3
Important Safety Information	. 4
Specifications	
Electrical	
Plumbing	
Ambient	
Heat Rejection	
Ice Production Chart	
Clearances	
Water	
Refrigeration	
Detailed Drawing	
Installation	
Uncrating Information	
Undercounter Installation	
Freestanding Model Installation	
Start-Up Procedure	
Before turning power on	
After turning power on	
Periodic Cleaning and Sanitizing	12
Condenser	
Cleaning/Descaling and Sanitizing	12
Service	16
Overview	16
Accessing Internal Components	17
Ice Bin Removal	
Water System	18
Electrical System	
Starting Procedure	
Diagnostic Stages.	
Wiring Diagram	
Compressor Data	
Compressor Data Compressor Current Draw at 220 Vac	32
Compressor Current Draw at 220 Vac	
Gearmotor Data	
Fan Motor Data	
Mechanical System	
Evaporator Disassembly	
Evaporator Reassembly	
Refrigeration System	35
Refrigeration Charge	
Troubleshooting	
· · · · · · · · · · · · · · · · · · ·	38

Welcome

Follett equipment enjoys a well-deserved reputation for excellent performance, long-term reliability, and outstanding after-the-sale support. To ensure that this product delivers that same degree of service, we ask that you take a moment to review this manual before beginning the installation. Should you have any questions or require technical help at any point, please call our technical service group at +48 58 785 61 40 for European market, and +1 877-612-5086 for US market.

Before You Begin

After uncrating and removing all packing material, inspect the equipment for concealed shipping damage. If damage is found, immediately notify the shipper and contact Follett Corporation so that we can help in the filing of a claim, if necessary. If needed, the serial number of your dispenser can be found by removing the grill and locating the serial number label (1) on the bin and on the bottom of the main frame (2).



Check your paperwork to verify that you received the correct dispenser. Follett configuration numbers are designed to provide information about the type of dispenser you are receiving. The following is an explanation of the different model numbers.

	U	F	С	425	Α	80	Р
	Product Type	Ice Type	Voltage	Icemaker Capacity	Condenser	Bin Capacity	Ingegrated Pump
ι	J Undercounter	F Flake M Micro Chewblet	C 220/60 D 115/60 E 230/50	425 Up to 425 lbs.	A Air cooled	80 80 lbs.	P yes — no



Important Safety Information

M CAUTION!

- For indoor use only. Designed for commercial use. Follett is not able to provide in-house services for residential installations.
- This appliance should be permanently connected by a qualified person in accordance with application codes.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Connect to potable water supply only.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should be supervised to ensure that they do not play with the appliance.
- Children should not be allowed to perform any maintenance of this appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant inside the bin!
- Warranty does not cover exterior or outside installations.
- Moving parts. Do not operate with front cover removed.
- Hot parts. Do not operate with cover removed.
- To reduce risk of shock, disconnect power before servicing.
- Follett recommends water filtration system. Contact Follett for more information.
- Most icemaker cleaners contain citric or phosphoric acid, which can cause skin irritation. Read caution label on product and follow instructions carefully.
- Ice is slippery. Maintain counters and floors around dispenser in a clean and ice-free condition.
- Ice is food. Follow recommended cleaning instructions to maintain cleanliness of delivered ice.
- To avoid potential contamination do not use the surface of the unit as a worktop.

Specifications

Electrical

- Power supply:
 - 230 V, 50 Hz, 1 phase, maximum machine amperage 5.1A, maximum fuse 10A (UME/UMC/UFE/UFC models)
 - 230 V, 60 Hz, 1 phase, maximum machine amperage 3.8A, maximum fuse 10A (UME/UMC/UFE/UFC models)
- Connect to dedicated circuit.
- Must be grounded (requires 3-prong outlet). Do not remove ground.
- Replacement cord instructions, if the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.

Plumbing

- 3/8" OD push-in water inlet
- 3/8" drain line can not exceed length limits. Drain line length is limited to 5 ft (1.5m) vertically and 16 ft (5m) horizontally
- Water supply and drainage line are similar in appearance do not swap

Notes:

- Unit is equipped with internal drain pump.
- Maximum drain line run is 5 ft (1.5 m) high and 33 ft (10 m) horizontal.
- Drain to be hard piped and insulated.
- To prevent back flow, do not connect drains.
- Water shut-off recommended within 5 ft (1.5 m)
- Drain line needs to be installed above the drain and with an air gap (according to local requirements)
- Follett recommends a Follett water filter system be installed in the ice machine inlet water line (standard capacity #00130229, high capacity #00978957, carbonless high capacity #01050442).

Ambient



This unit is for indoor use only.

Air temp*	100 F/38 C max. 50 F/10 C min. Best performance below 80 F (27		
Water temp [†]	90 F/32 C max. 40 F/7 C min. Best performance below 70 F		
Water pressure	70 PSI/5 Bar max. 10 PSI/0.7 Bar min.		
Relative humidity	55% at 78 F (25,5 C)		

^{*} Use outside of these limits is misuse and will void warranty.

Heat Rejection

■ 5000 BTU/hr



[†] Best performance is achieved between 80 F (27 C) and 50 F (10 C).

Ice Production Chart

Air-Cooled icemaker capacity/24hrs.

Ambient Air Temperature F/C

	F	60	70	80	90	100	
	С	16	21	27	32	38	
	50	510	454	397	335	273	lb
၁	10	232	206	180	152	124	kg
F/C	60	484	435	389	329	270	lb
emperature	16	219	198	177	150	123	kg
era	70	454	417	380	323	266	lb
emp	21	206	190	173	147	121	kg
	80	424	385	347	297	247	lb
Water	27	193	175	158	135	112	kg
et V	90	394	354	313	270	227	lb
Inlet	32	179	161	142	123	103	kg

Dimensions

Width	23.43" (59,5 cm)
Depth	25.98" (66,0 cm)
Height	32.99" (83,8 cm)
Height with legs	38.90" (98,8 cm)
Unit shipping weight	185 lb (84 kg)
Unit net weight	154 lb (70 kg)

Clearances

• This unit is a front-breathing device. No side and back clearances needed.

Water

⚠ CAUTION!

- Connect to potable water supply only.
- Not recommended for use with softened water
- Ingress Protection (IP) rating: IPX0 (no protection)
- Water pressure: 10–70 psi (69–483 kPa)


Refrigeration


M CAUTION!


- Do not damage the refrigerant circuit. Refrigerant can cause personal injury and/or damage dispenser.
- Refrigerant R404a 435 g (15.34 oz.).

Detailed Drawing

With 6" Legs









- 1 3/8" OD push-in water inlet
- 2 3/8" OD push-in water drain
- 3 Power supply cable entry grommet
- 4 Power cord connection

With Leveling Feet





Installation

CAUTION!

- For indoor use only. Designed for commercial use. Follett is not able to provide in-house services for residential installations.
- Use caution when tipping the dispenser during leg installation. Do not lay unit on back or side. DO NOT EXCEED 30° angle. Tipping more than 30° can result in compressor malfunction.

Uncrating Information

- 1. Carefully unpack and inspect the contents of your Follett icemaker.
- **2.** Unscrew all four bolts fastening the machine to the skid.
- 3. Slide the unit to one side of the skid and screw in supplied accessory leg set or leveling feet according to your machine setup.





Fig. 2 - Leg Set (Freestanding) or Leveling Feet (Undercounter) Option





Screw, hex HD cap, 5/18-11 x 1-3/4

Undercounter Installation

Install icemaker section first, to ease installation procedure. Installation instructions for freestanding model may be found on page 10.

Bin portion must be removed after uncrating

- 1. Remove the front grille (Fig. 3.1).
- 2. Remove two screws behind the grille (Fig. 3.2).
- 3. Remove the drain tube from the ice bin (Fig. 4).
- **4.** Facing the unit, slide the bin out by pulling it towards you.

Rough-in the electrical service and water line

- Unit is provided with a 2.4 m IEC power cord.*
 - UFC, UMC family (220 V/60Hz)
 - UFE, UME family (230 V/50 Hz)
- Water: supply line (with shut-off valve) connects to the dispenser's (3/8" OD push-in water inlet)

Note: This appliance is intended to be permanently connected to water main using 3/8" OD tubing.

- Connect water line and drain. Maximum drain line run is 5 ft (1.5 m) high and 33 ft (10 m) horizontal. Recommended routing (Fig. 5) allows easy access to water for cleaning and sanitizing procedure. Verify the bin drain shutoff valve is open (Fig. 4).
- 2. Connect power supply.
- 3. Unit must be level to operate properly.
- Install bin portion after all supplies are connected.
- **5.** Sanitize the dispenser prior to use (see Cleaning and Sanitizing on page 12).
- * Depending on the market, the user must install the proper plug per local electrical code (plug not included.)

Fig. 3




Fig. 4







Fig. 5 - Undercounter




Freestanding Installation

- 1. Rough-in the electrical service and water line
 - Unit is provided with a 2.4 m IEC power cord. Depending on the market, the user must install the proper plug per local electrical code (plug not included.):
 - UFC, UMC family (220 V/60 Hz)
 - UFE, UME family (230 V/50 Hz)
 - Water: supply line (with shut-off valve) connects to the dispenser's 3/8" OD push-in water inlet.

Note: This appliance is intended to be permanently connected to water main using 3/8" OD tubing.

- 2. Connect water line and drain. Recommended routing (Fig. 6) allows easy access to water for cleaning and sanitizing procedure. Ensure that the water drain valve is open (Fig. 4).
- 3. Connect power supply.
- 4. Ensure that the unit is level. Unit must be level to operate properly.
- 5. Sanitize the dispenser prior to use (see Cleaning and Sanitizing on page 12).

Fig. 6 - Freestanding



Start-Up Procedure


Before turning power on

- 1. Clean and sanitize ice bin in accordance with cleaning procedure.
- 2. Turn water to icemaker ON.

After turning power on

- 1. Turn ON the machine with on/off switch and confirm that gearmotor, compressor and fan motor start.
- 2. Check that ice begins to enter bin within approximately 5 minutes.
- 3. After making ice for 5 minutes, put ice against ice level thermostat tube (Fig. 7) and check that icemaker shuts down.
- 4. Warm the ice level thermostat tube with your fingers and check that icemaker restarts in approximately 20 minutes (bin must be calling for ice).

Fig. 7



Periodic Cleaning and Sanitizing

Follett ice machines and dispensers, and their associated cleaning and sanitizing procedures, are designed for use with potable water sources. The presence, or suspected presence, of infectious agents may call for additional measures, including the replacement of components and more comprehensive disinfection measures. Follett recommends that these cleaning and sanitizing procedures be reviewed with the appropriate infectious agent subject matter experts to assure complete remediation.


Periodic cleaning of Follett's ice machine system is required to ensure peak performance and delivery of clean, sanitary ice. The recommended cleaning procedures that follow should be performed at least as frequently as recommended and more often if environmental conditions dictate.

Cleaning of the condenser can usually be performed by facility personnel. Cleaning of the ice machine system should be performed by your facility's trained maintenance staff or a Follett authorized service agent. Regardless of who performs the cleaning, it is the operator's responsibility to see that this cleaning is performed according to the schedule below. Service problems resulting from lack of preventive maintenance will not be covered under the Follett warranty.

Condenser

Unit is supplied with condenser filter (**Fig. 8**). At least once per month use a vacuum cleaner or stiff brush to clean condenser filter and evaporator coils of lint and debris to ensure optimal performance. To access condenser filter remove plastic front cover grille.

Fig. 8



Cleaning

Cleaning and sanitizing should be performed at least every 6 months (more often if local water conditions dictate). For initial startup, only sanitizing is required.

CAUTION!

- Wear rubber gloves and safety goggles (or face shield) when handling SafeCLEAN Plus solution.
- Use only Follett approved cleaners.
- Do not use solvents, abrasive cleaners, metal scrapers or sharp objects to clean any part of the dispenser.

Required Supplies

- SafeCLEAN™ Plus ice machine cleaner
- (2) SaniSpongeTM (PN 00131524 single sponge)
- Funnel and bucket

SafeCLEAN Plus Solution: Follow the directions on the SafeCLEAN Plus packaging to mix 1 gal. (3.8 L) of Follett SafeCLEAN Plus solution. Use 100 F (38 C) water.

- **1.** Remove front grille to access internal components (**Fig. 9**).
- Press clean switch on the main control box.
 The MAINTENANCE light will turn on and the machine will drain. Wait for the LOW WATER light to turn on (Fig. 10).
- Remove lid from cleaning cup (Fig. 11) and fill (about 1 quart) until SafeCLEAN Plus solution completely fills the reservoir. Place lid back on cup.
- CLEANER FULL light will turn on and machine will start cleaning cycle then rinse three times; this process takes approximately 15 minutes.
- **5.** When machine is finished cleaning, the **MAINTENANCE** light will turn off.
- **6.** Remove any remaining cleaner from tube and cleaning cup.

Note: The next steps must be completed before machine flushes and starts producing ice!

Fig. 9




Fig. 10






Fig. 11





7. Using disposable food service grade gloves, insert one **dry** Sani-Sponge[™] (**Fig. 12.1**). Next, insert one Sani-Sponge soaked in SafeCLEAN Plus solution (**Fig. 12.2**). Push both of the Sani-Sponges down ice transport tube (ice chute outlet) with supplied pusher tube (**Fig. 12.3**).

Fig. 12



- 8. Remove and discard pusher tube (Fig. 13).
- 9. When sanitizing cycle ends, the MAINTENANCE light will turn off and machine will start producing the ice. Ice pushes Sani-Sponges through the tube.
- Place a sanitary (2 gallon or larger) container in bin to collect Sani-Sponges and ice for 10 minutes. Collect 5.5 lbs (3 kg) of ice from unit. Discard ice and Sani-Sponges (Fig. 14).

Fig. 13





Fig. 14



- 11. Drain pump needs regular inspection every six months. To access the pump, it is necessary to remove the ice bin (Page 9). Unscrew four screws (Fig.15) and carefully lift the top housing. Clean the tank surface and the strainer installed inside. Check the pump rotor - it should rotate freely and without any sound
- **12.** Check the float. When you lift and drop the float, it should move easily.


Cleaning bin before use and ongoing bin maintenance

Interior of bin must be cleaned and sanitized prior to use and should be cleaned on a routine basis during use.

Interior bin care

Bin is equipped with polyethylene liner and stainless steel elements that should be cleaned and sanitized periodically with products suitable for use in a food zone. While cleaning and sanitizing the thermostat capillary tube bracket area, use products that are non-aggressive to such materials. After cleaning and sanitizing, rinse thoroughly with potable water.

Fig. 15





Service

M CAUTION!

No service or maintenance should be performed until the technician has thoroughly read this service manual. Except for routine cleaning and sanitizing, only qualified technicians should attempt to service or maintain this equipment.


Overview

How the Machine Works

Follett's automatic-load icemaker is equipped with Follett's 425 lb (193kg)/day ice technology. In the continuous icemaking process, water freezes to the inside wall of the evaporator. A rotating stainless steel auger carries the ice to the top of the evaporator where it is compressed and extruded through an outlet port. The ice is then pushed through a tube to the integrated ice storage bin. When the bin is full, a bin thermostat opens and turn OFF the icemaker.

A solid state control board located in the electrical box of the icemaker controls the normal operation of the icemaker and monitors gearmotor torque. This control board will shut down the icemaker should an overtorque condition occur. It is very important that you familiarize yourself with the operational sequences detailed in this manual before attempting to service the icemaker.

Ice enters the integrated ice bin. Using the scoop supplied with the unit, you can easily take the ice out of the bin. There is a scoop holder located on the internal wall. When ice is emptied from the ice bin, the thermostat capillary tube gets warm and signals the machine to produce ice. There is no need turn off the machine during its normal operation.





Accessing Internal Components

CAUTION!

- Except for routine cleaning and sanitizing, only qualified technicians should attempt to service or maintain this
 equipment.
- Use caution when sliding out the bin.

Ice Bin Removal

- 1. Empty all the ice from the bin.
- 2. Remove the front grille (Fig. 16.1).
- 3. Remove two screws behind the grille (Fig. 16.2).
- **4.** Shut off the bin drain valve and remove the drain tube from the ice bin **(Fig. 17)**.
- **5.** Facing the unit, slide the bin out by pulling it towards you.

Fig. 16





Fig. 17





Water System

The water level in the evaporator is controlled by a feed solenoid and level detecting sensors. Referencing the diagram below, water sensing rods extend down into the reservoir. The system works via electrical conductivity as follows:

One of the longest probes is a Common. When water is between any of the other probes and the common, the PC board will sense the activation. During normal operation, the water level rises and falls between the Normal High and Normal Low sensors. As water is consumed to make ice, the water level will fall until the Normal Low sensor is exposed, triggering the water feed solenoid to turn on. Water will fill until the Normal High sensor is activated.

Note: The potable water dissolved solids content must be greater than 10 ppm for the water control system to function properly. If using a reverse osmosis water filtration system, ensure TDS (total dissolved solids) level is greater than 10 ppm.

Fig. 18




Fig. 19 - Water Reservoir





Fig. 20



- Push in water inlet 3/8"
- Check valve
- Water feed solenoid valve 3
- Water reservoir
- 5 Purge valve

- Drain outlet 3/8"
- Evaporator and gearmotor assembly lce compression nozzle Drain pan 7

Electrical System

ATTENTION!

To prevent circuit breaker overload, wait 15 minutes before restarting this unit. This allows the compressor to equalize and the evaporator to thaw.

Normal Control Board Operation

The PC board indicator lights provide all the information necessary to determine the machine's status. Green indicator lights generally represent "go" or normal operation; Yellow indicators represent normal off conditions; Red indicators generally represent alarm conditions, some of which will lock the machine OFF.

A flashing green light labeled POWER indicates power to the machine. All other normal operation status indicators are covered as follows:

Icemaker disposition					perating conditions
	Legend: • ON	○ OFF	ON or OF	F	☼ FLASHING
1.	CLEANER FULL BAIN CLOG OPAIN CLOG	IIME DELAY SLEEP CYCLE MAKING ICE LOW BIN		1.	Normal running.
2.	C CLEANER FULL DRAIN CLOG DRAIN CLOG HI PRESS HI AMPS SERVICE MAINT/CLEAN OLOMATER DE THE CLOSE OF THE CLOSE	SLEEP CYCLE MAKING ICE LOW BIN POWER ON		2.	Normal time delay. When the bin fills with ice, the LOW BIN light goes out momentarily and the refrigeration and auger drive systems immediately shut down. (Note: The fan motor will continue to run for 10 minutes to cool condenser). The TIME DELAY LED lights, initiating the time delay period. When the time delay expires, the machine will restart as long as the LOW BIN light is on.



Error Faults:

The PC board monitors various operating parameters including high pressure, auger gearmotor amperage limits, and low water alarm conditions. There are two types of errors namely "hard" or "soft". A hard error is one that shuts the machine off and will not allow restart until the reset button is pressed. Even cycling power will not reset a hard error.

A soft error can either be automatically reset should the condition rectify, or if power is cycled. Should an error occur, consult the troubleshooting guide in this manual or a Follett service technician.

Soft Errors:

HI AMPS: The PC board monitors the amperage of the auger motor. Should the gear motor experience current draw above the allowable limit, the machine will shut down and the **TIME DELAY** and **HI AMP** will be illuminated. After the time delay, the machine will restart and the **TIME DELAY** and **HI AMP** will clear. HI AMPS will also occur if the PC board detects no gear motor amperage (0A - gear motor disconnected).

LO WATER: During operation, the water level cycles between the normal low and normal high sensors. Should the water be shut off to a running machine, a soft error will occur. The error sequence is as follows: During operation, the water level falls to the normal low sensor, and when it does the water feed solenoid is energized. If water is not detected at the normal low sensor within 10 seconds, a soft error will occur. The machine will shut down, but the water feed solenoid will remain energized. Should water return, it will fill to the normal low sensor and the machine will resume normal operation. The error will clear automatically.

HI PRESSURE: Should the refrigeration pressure rise above 425 psi, the machine will shut down and the **TIME DELAY** and **HIGH PRESSURE** will be illuminated. After the time delay, and if the pressure has fallen back below the reset point of 295 psi, the machine will restart and the **TIME DELAY** and **HIGH PRESSURE** will clear.

Hard Error:

HI AMPS: If a second hi-amp error occurs within 1 hour of the initial hi-amp error, the icemaker will shut off and the reset on the board must be pressed to clear the error. If a second hi-amp has occurred, the **HI AMP** LED only will be illuminated.

DRAIN CLOG: The drain clog sensor, located in the evaporator drain pan will detect the presence of water just below the top edge of the pan. If water does not properly flow out of the internal or external drain lines it will backup into the drain pan (especially during a self-flushing purge cycle). Pressing the reset button will restart the ice machine.

Relay/triac Output Indication:

Each relay on the board has an indicator light associated with its output. For example, when the relay for the water feed solenoid is energized, the adjacent indicator light glows green.

Flushing Logic:


Off cycle: At the completion of off-cycle time delay, the machine checks for a cumulative one (1) hour of ice making time since the last off-cycle flush. If the cumulative ice making time exceeds one (1) hour, the machine will open the drain valve for 60 seconds to drain the evaporator in its entirety. It will then refill with water and begin making ice. If the ice making time is less than 1 hour, the machine will start and begin making ice without draining the evaporator.



Starting Procedure


Normal Operation - Stage 1

Power is supplied to L1 of the control board, the **POWER** LED light begins flashing. The ice level bin thermostat in the dispenser is closed and calling for ice, supplying contact closure to the control board. The **LOW BIN** LED will be lit. The control board will now go through the start-up sequence. The board checks the water sensors (located in the reservoir) for continuity between the common probe (B) and the high probe (C). If continuity is not sensed, the water fill valve (P21) is energized.




Normal Operation - Stage 2

When continuity is seen between B and C, the water valve de-energizes, the AUGER output (P4) comes on along with the **MAKING ICE** LED. The auger gearmotor's start windings are energized through a current style start relay that is pulled in by the initial high current draw of the gearmotor.




Normal Operation - Stage 3

After the initial high current draw drops off, the gearmotor start relay contacts open, dropping out the start winding. The condenser fan output (P3) comes on 0.5 seconds later.



Normal Operation - Stage 4


One second (1 s) after the fan comes on, the **COMPRESSOR** output comes on. The compressor circuit uses both run and start capacitors along with a potential start relay. The start capacitor in energized through the normally closed contacts of the start relay.



Normal Operation - Stage 5


As the compressor comes up to normal running speed, its start winding generates a voltage potential across the relay's coil. This energizes the coil to open the contact and drop out the start capacitor.

The icemaker is now in a normal ice making mode. The icemaker will produce ice until the bin level control in the ice dispenser is satisfied.




Normal Operation - Stage 6

Once the bin thermostat control opens, the **LOW BIN** LED goes out. After a 10 second delay the compressor output turns off, the **MAKING ICE** LED goes out and the **TIME DELAY** LED comes on.




Normal Operation - Stage 7

The fan motor continues for 10 minutes before shutting off. The **TIME DELAY** LED remains on for 20 minutes. The icemaker will not start while the **TIME DELAY** LED is on. To restart the icemaker for troubleshooting purposes, depress the reset button to clear the control board.




Normal Operation - Stage 8

When the dwell time of 20 minutes has expired, the **TIME DELAY** LED goes off. If 5 seconds of ice has been dispensed and the **SLEEP CYCLE** LED is off, the icemaker will go through the normal start-up sequence when the bin level control signals the control board for ice.



Self-flushing

At the completion of the 20 minute time delay, the machine checks for a cumulative one hour of ice making time since the last off-cycle flush. If the cumulative ice making time exceeds one hour, the machine will energize the drain valve P19 for 60 seconds to drain the evaporator. It will then refill with water, flush again, refill and begin making ice if the **LOW BIN** LED is on. If the ice making time is less than 1 hour, the machine will start and begin making ice without draining the evaporator.






Diagnostic Stages

High Gearmotor Amps - Stage 1


The **HI AMPS** error and **TIME DELAY** LEDs are on indicating that the control board has sensed an over-torque condition at the P4 terminal (more than 3A from the gearmotor) and shut the icemaker down (strike one). The **HI AMPS** and **TIME DELAY** LEDs will remain on for 60 minutes after an over-torque condition has occurred. The icemaker will remain off as long as these two LEDs are on. After the 60 minute time delay, these LED lights turn off, and the control board will try to go through a normal start-up sequence.






High Gearmotor Amps - Stage 2

If the restart is successful the board will continue to monitor the current draw on P4 for 60 minutes looking for a second high amps (above 3A) occurrence. If the icemaker runs without problems for 60 minutes and no additional torque errors occur, the icemaker will continue normal operation.




High Gearmotor Amps – Stage 3

If a second occurrence happens during the 60 minute monitoring period, the **HI AMPS** LED will come on again and shut the machine down (strike two). The **HI AMPS** LED (without the **TIME DELAY** LED) will indicate to the technician that two consecutive over-torque situations have occurred. The icemaker is shut down at this time and locked out. It will not restart unless the manual reset button is depressed while power is on.



Loss of Water


During operation, the water level cycles between the normal low (D) and normal high (C) water probes - the fill valve (P21) cycling on and off. If continuity is not detected between the common probe (B) and normal low (D) within 10 seconds, the **LOW WATER** and **TIME DELAY** LEDs will come on and the machine will shut down for the one hour time delay period. After the time delay, the fill valve will re-energize and wait for continuity between the common probe and normal high before restarting. **LOW WATER** LED will remain on until the water level is satisfied.






High Refrigerant Pressure

Should the refrigeration pressure rise above 425 psi, the high pressure switch contacts will open. The board sees the open circuit and the **HIGH PRESSURE** and **TIME DELAY** LEDs will come on, the machine shuts down. After the one hour time delay, the machine will attempt to restart. If the pressure has fallen below the reset point of 295 psi and the board see the contacts closed, the machine will resume normal operation. If the contacts are still open after the restart, the board will again go into **HIGH PRESSURE** and **TIME DELAY**, cycling until contact closure is seen.




Drain clog

If continuity is seen between the two drain clog sensor probes, the **DRAIN CLOG** LED will come on and the machine will shut down. The machine will not restart unless the manual reset button is depressed while power is on.



Wiring Diagram





Compressor Data

Compressor Current Draw at 220 Vac

Ambient air temperature	60 F/15.6 C	70 F/21.1 C	80 F/26.7 C	90 F/32.2 C	100 F/37.8 C
Amperage	3.26A	3.3A	3.38A	3.45A	3.55A
High-side pressure (bar/psi)	12.2/177	14.4/209	16.8/244	18.4/267	20.8/302
Low-side pressure (bar/psi)	1.5/22	1.7/25	1.8/26	2.0/29	2.2/32

Locked rotor amps 30A @ 220 V, 60 Hz

Compressor Current Draw at 230 Vac

Ambient air temperature	60 F/15.6 C	70 F/21.1 C	80 F/26.7 C	90 F/32.2 C	100 F/37.8 C
Amperage	3,15A	3,20A	3,25A	3,35A	3,45A
High-side pressure (bar/psi)	11,8/171	14/203	16,2/235	19/275,5	22/319
Low-side pressure (bar/psi)	2/29	2,13/31	2,27/33	2,4/35	2,55/37

Locked rotor amps 18.2A @ 230 V, 50 Hz

Gearmotor Data

	220 V	230 V
Gearmotor current	0.98A (nominal)	1.3A (nominal)
Gearmotor torque-out (high amp) trip point	1.4A	1.8A
Locked rotor amps	6.8A	6.8A

	220 Vac	230 Vac
Resistance of windings	Yellow to black: 45 Ω	Yellow to black: 45 Ω
	Black to blue: 29.5 Ω	Black to blue: 29.5 Ω
	Blue to yellow: 16.2 Ω	Blue to yellow: 16.2 Ω

	220 V	230 V
Compressor start winding	7.5 Ω	11.4 Ω
Compressor run winding	2.7 Ω	4.9 Ω

Fan Motor Data

	220 V	230 V
Fan motor current	0.2 Ω	0.22 Ω




Mechanical System

Evaporator Disassembly

- 1. Press **CLEAN SWITCH** to purge evaporator.
- Disconnect power to icemaker when LOW WATER lights.
- 3. Shut off water to icemaker.
- 4. Disconnect plastic tubing from evaporator water inlet, drain pan stub, compression nozzle tubing and reservoir overflow tubing from secured clip.
- **5.** Disconnect ice transport tube from compression nozzle.
- **6.** Loosen nut and remove upper vee-band coupling from top of evaporator.
- 7. Lift top bearing assembly straight up with a slight rotating motion and remove.
- **8.** Remove ice compression loop located at top of auger.
- 9. Lift auger straight up and out of evaporator.
- **10.** Remove nut and lower vee-band coupling from bottom of evaporator.
- **11.** Lift evaporator to clear bottom bearing assembly.
- **12.** Loosen hex head bolt in side of mounting base with 5/16 wrench and lift lower bearing assembly.
- 13. Remove condensate shield.
- **14.** Remove four allen head machine screws holding mounting base to gearbox.
- **15.** If replacing evaporator, remove compression nozzle from evaporator port.

Fig. 21






Evaporator Reassembly

- 1. Clean gearmotor boss, output shaft and shaft well.
- 2. Install drain pan and evaporator mounting base.
- 3. Fill gearmotor shaft well with food-grade grease.
- 4. Install condensate shield and seat against gearmotor boss.
- 5. Install mounting base O ring in groove in evaporator mounting base.
- 6. Lower bottom bearing assembly into evaporator mounting base.
- **7.** While maintaining a downward pressure on bottom bearing assembly, tighten hex head bolt with a 5/16 wrench.
- 8. Position evaporator over lower bearing assembly and align grooves with pins in bearing assembly.
- **9.** Install vee-band clamp and nut and tighten to 70 in/lb.
- 10. Place auger in center of evaporator and rotate to mate with drive pin.
- 11. Install ice compression loop, orienting loop as shown.
- **12.** Install upper bearing and seal assembly, rotating bearing to slip pin into auger slot.
- 13. Install upper vee-band clamp and nut and tighten to 70 in/lb.
- 14. If evaporator was replaced, reinstall compression nozzle.



Refrigeration System



Refrigeration Charge

All service on refrigeration systems must be performed in accordance with all federal, state and local laws. It is the responsibility of the technician to ensure that these requirements are met. Recharging icemaker to other than factory specifications will void the warranty.

R425 icemaker charge specifications

Model	Charge	Refrigerant type	
UME425A80; UMC425A80; UFE425A80; UFC425A80	15.34 oz (435 g)	R404A	

CAUTION!

Recharging of unit at other than factory specifications will void icemaker warranty.

Ice Capacity Test

Icemaker production capacity can only be determined by weighing ice produced in a specific time period.

- **1.** Remove top panel and hopper lid of unit.
- 2. Weigh and record weight of container used to catch ice.
- 3. Run icemaker for at least 15 minutes.
- 4. Catch ice for 15 or 20 minutes.
- 5. Weigh harvested ice and record total weight.
- 6. Subtract weight of container from total weight.
- **7.** Convert fractions of pounds to decimal equivalents (Ex. 6 lbs 8 oz = 6.5 lbs).
- 8. Calculate production using following formula:

1440 min. x wt. of ice produced
Total test time in minutes

= Production capacity/24 hr. period

9. Calculated amount per 24 hours should be checked against rated capacity for same ambient and water temperatures in Ice Production Table (see page 6).

Discharge Pressure/Suction Pressure - 220 V/60 Hz

		Ambient Air Temperature F/C			
	F/C	60/16	80/27	100/38	
Icemaker Inlet Water Temperature F/C	50/10	177/22	249/25	302/32	psig
	50/10	12/2	17/2	21/2	bar
	70/21	1770/23	247/28	305/35	psig
	70/21	13/2	17/2	21/2	bar
	90/32	186/25	261/30	348/39	psig
	30/32	13/2	18/2	24/3	bar

Discharge Pressure/Suction Pressure – 230 V/ 50 Hz

		Ambient Air Temperature F/C			
	F/C	60/16	80/27	100/38	
Icemaker Inlet Water Temperature F/C	50/10	186/21	249/25	336/36	psig
		13/1	17/2	23/3	bar
	70/04	181/23	247/29	340/38	psig
	70/21	13/2	17/2	24/3	bar
	00/20	186/25	268/33	355/41	psig
	90/32	13/2	19/2	25/3	bar




Troubleshooting

Ice	maker disposition	Possible causes	Corrective action
	Legend: ON OFF ON	or OFF	
1.	C CLEANER FULL condition on the press of H AMPS of LOW WATER OF LOW WATER OF SLEEP CYCLE OF LOW BIN MAKING ICE MAKING ICE LOW BIN POWER ON POWER ON	 Defective compressor. Defective start relay. Defective start capacitor. Defective run capacitor. Defective main contactor. No output from PC board. Machine in Purge cycle. 	 Replace compressor. Replace start relay. Replace start capacitor. Replace run capacitor. Replace main contactor. Replace PC board. Check for Purge operation.
2.	CLEANER FULL DRAIN CLOG HIPRESS HIAMPS SERVICE MAINT/CLEAN TIME DELAY TIME DELAY SLEEP CYCLE MAKING ICE MAKING ICE DLOW BIN POWER ON POWER ON	Damaged or improperly installed thermostat (open).	1. Replace or reposition thermostat.
3.	CLEANER FULL WANTER FULL WANTER FULL WANTER OF HIAMPS HIAMPS SERVICE O MAINT/CLEAN TIME DELAY TIME DELAY O SLEEP CYCLE O MAKING ICE O LOW WATER O LOW BIN POWER ON	 Poor water quality causing ice to jam auger. Ice transport tube damaged or bent. Intermittent drive output from PC board. Evaporator will freeze causing a hi amps error. Gearmotor is unplugged. 	 Clean icemaker. Inspect ice transport tube - replace if needed. Replace PC board. Plug in gearmotor.
4.	CLEANER FULL AND CLOR STAND CLOR WIND CLOR SERVICE OF THE PELS OF THE PELAY OF THE	 High ambient temperatures >100 F (38 C). Poor ventilation or air circulation. Clogged condenser or condenser filter. Fan not working properly. No air flow. Blocked fan blades No fan output from PC board Faulty fan motor Icemaker is making ice. Excessive water in bin from transport tube. 	
5.	CEEANER FULL CLEANER FULL CLEANER FULL CLEANER FULL O DRAIN CLOG O HI AMPS SERVICE O MAINT/CLEAN O MAKING ICE	 Failed water sensors. Processor assumes there is no water when there is water. Blocked reservoir vent. Defective water feed solenoid valve. Stuck in open position. 	Clean or replace water probe assembly. Check wiring connections. Clean or replace vent tubes Replace water feed solenoid valve.
6.	CLEANER FULL LAMPS O DRAIN CLOG O HI AMPS O SERVICE O MAINT/CLEAN O TIME DELAY O SLEEP CYCLE O MAKING ICE O MAKING ICE O POWER ON O POWER ON O POWER ON	 R. 1. Water supply is insufficient 2. Low water pressure. 3. Defective water feed solenoid valve. Stuck in closed position. 4. No water feed output from PC board. 	Restore water supply and check water filters. If evaporator was completely empty the reset button may have to be pressed to restart the icemaker. Icemaker will eventually start when water reaches normal LO level. Replace water feed solenoid valve. Replace PC board.
2.	CLEANER FULL DAILY	 Drain pipe clogged or bent. Contamination in drain pump tank. Defective pump 	 Unlock drainage pipe and press reset button. Inspect pump. Check if tank and strainer are clean. Ensure float and rotor work freely. Replace pump.



Replacement Parts


Evaporator Assembly



Reference #	Description	Part #
1	Coupling, vee-band, includes nut	502735
2	Bearing assembly, top	502736
3	Loop, ice compression, beveled	502110
3a	Loop, ice compression, notched (Flaker component)	00124115
4	Auger	502737
4a	Auger, with paddle (Flaker component)	00124123
5	Evaporator assembly (does not include insulation jacket)	01096205
6	O-ring, bearing housing	500496
7	Bearing assembly, bottom	502738
8	O-ring, mounting base	501063
9	Shield, condensate	500744
10	Screw, Allen 1/4 20 x 1/2 (set of 4)	501080
11	Mounting base, evaporator (includes 501063)	502733
12	Bolt, mounting base	502227
13	Gearbox & motor 220 V 60 Hz/230 V 50 Hz	502832
Not shown	Mounting base, gearbox	01067693
15	Compression nozzle, Micro Chewblet, assembly	01092584
16	Compression nozzle, Flaker, assembly	01092592
17	Screw, compression nozzle mounting	00911743
18	Drain pan, evaporator	00181990
Not shown	Grease	501111
19	Bracket, drain hose	01007087
20	Insulation jacket, evaporator	00946392
Not shown	Relay, gearmotor 220 V/60 Hz, 230 V/50 Hz	00120055
21	Cover, plastic	01012228
Not shown	Insulation, compression nozzle	01092568




Components Assembly



Reference #	Description	Part #
1	Compressor, 230 V 50 Hz	01079599
1	Compressor, 220 V 60 Hz	01079607
2	Filter, dryer	00177527
3	Switch, high pressure	00117077
4	Valve, expansion	01079615
5	Condenser	01079433
6	Fan motor	01292564
7	Fan cover	01292572
8	Fan blade	01292580
9	Compression Nozzle, Flaker, assembly	01092592
9	Compression Nozzle, Micro Chewblet, assembly	01092584
10	Pan, drain	00181990
11	Tube, sanitizer	01092865
12	Tube, water feed	01056225
13	Tube, drain line	01162064
14	Water reservoir assembly	01093517
15	Valve, water feed solenoid 220 V 60 Hz/230 V 50 Hz	00116848
16	Valve, check	01066166
17	Valve, purge 220 V 60 Hz/230 V 50 Hz	00991190
18	Cup, cleaning	01065226
19	Tube, ice transport (includes insulation and clamp)	01079623
20	Bin thermostat	500514
21	Capacitor, compressor run 220 V 60 Hz	01082528
21	Capacitor, compressor run 230 V 50 Hz	01082551
22	Tube, nozzle vent	01092857
23	Tube, nozzle to reservoir	01098862
24	Lid, water reservoir (includes screws, probes, elbow and gasket)	01099118
25	Gasket, water reservoir	00990978
26	Overload switch, compressor (230 V 50 Hz)	01099191
26	Overload switch, compressor (220 V 60 Hz)	01099217
27	Water inlet, push in	00976787
28	Pump, drain VCC-20S-230 V	01200005




External Components



Reference #	Description	Part #
1	Grille, front cover	01079474
2	Frame, door assembly	01079482
3	Guide, door slide left	01079490
4	Guide, door slide right	01079508
5	Sliding doors	01079540
6	Roller, doors	01056407
7	Scoop	01056415
8	Holder, scoop	01066406
9	Filter, condenser	01058544
10	Cover, top	01032556
11	Cover, front stainless steel blend	01079532
12	Legs, 6" (150 mm) accessory (set of 4)	205440
13	Feet, leveling (each)	01066224


Electrical Box



Reference #	Description	Part #
1	Cover, includes thumbscrew	01079573
2	Main board 220 V/60 Hz, 230 V/50 Hz (includes stand-offs)	01092550
3	Label, LED	01016914
4	Capacitor, compressor start 230 V 50 Hz	01082569
4	Capacitor, compressor start 220 V 60 Hz	01082536
5	Relay, compressor start 230 V 50 Hz	01082577
5	Relay, compressor start 220 V 60 Hz	01082544
6	Stand-offs 220 V 60 Hz/230 V 50 Hz	01066208
7	Switch, clean	01066539
8	Grommet	00177907
9	Inlet, power supply plug IEC	01300508
10	Frame, electric box	01061092
11	Switch, on/off	01086024
12	Thumbscrew, knurled	01082791
Not Shown	Cord, 220 V 60 Hz/230 V 50 Hz	01066547
13	Socket, pump relay	01257484
14	Time module, pump relay	01257492
15	Relay, pump	01257476



Bin Drain



Reference #	Description	Part #
1	Bin drain fitting	01066042
2	Elbow 3/4"	01066018
3	Bin drain valve (includes gasket)	01066026

Water Connections 220 V 60 Hz/230 V 50 Hz


Reference #	Description	Part #
Not shown	3/8" push-in x 1/2" BSP	01083211
Not shown	3/8" tubing x 3 m	208592

Drain Line Components 220 V 60 Hz/230 V 50 Hz

Reference #	Description	Part #
Not shown	3/4" drain elbow	01092519
Not shown	3/4" barbed thread	01092501
Not shown	3/4" tubing (25,3 mm x 3 m)	00949917
Not shown	Clamp	01083278




Micro Chewblet Nozzle



Reference #	Description	Part #
1	Ice breaker	01066794
2	Nozzle, compression	01066802
3	O-ring, 22 x 3	01081074
4	Screw, M5 x 10	00911743
5	Holder with clamp, nozzle	01073303
6	O-ring, 22 x 2	01081066
7	Screw, M5 x 16	00911750
Not shown	Insulation, compression nozzle	01092568

Flaker Nozzle



Reference #	Description	Part #
1	Nozzle, flaker	01076876
2	O-ring, 22 x 2	01081066
3	Screw, M5 x 10	00911743
Not shown	Insulation, compression nozzle	01092568

Icemaker Cleaner/Descaler

00132001	SafeCLEAN environmentally-friendly cleaner, carton of 24 x 7 oz packets

Icemaker Sanitizer

00979674	Nu-Calgon IMS-II Sanitizer, 16 oz. bottle
00131524	Sponge, sanitary, each

Water Treatment Accessories

Reference #	Description	Part #
Standard capacity filter system		
Not shown	Follett QC4-FL4S water filter system (includes FL4S primary cartridge and head, coarse pre-filter and head, pressure gauge, flushing valve; assembled and installed on mounting bracket), one per ice machine	00130229
Not shown	Follett FL4S primary replacement cartridge	00130245
Not shown	Water filter cartridge – primary, carton of 6	00954297
Not shown	Everpure coarse pre-filter cartridge	00130211
Not shown	Water pre-filter cartridge – pre-filter, carton of 12	00954305
Carbonless high capacity filter system		
Not shown	Carbonless high capacity water filter system (one per ice machine) – Horizon™ and MaestroPlus series ice machines	01050442
Not shown	Carbonless high capacity water filter cartridge – primary, single	01050426
Not shown	Carbonless high capacity water filter cartridge – primary, carton of 6	01050434
Not shown	Water pre-filter cartridge – pre-filter, single	00130211
Not shown	Water pre-filter cartridge – pre-filter, carton of 12	00954305



Micro Chewblet and SafeCLEAN Plus are trademarks of Follett LLC. Chewblet and Follett are registered trademarks of Follett LLC, registered in US.

